

Pearl

How to use the PML ST –8 stereo microphone.

Different Stereo modes

MS –recording.

1. Turn the microphone and direct the engraved sign PML to the centre of the sound field. The front membrane of the top capsule is the “M” channel. Use it as a cardioid pattern.
2. The bottom capsule has to be set as figure of eight.

Blumlein recording

Turn the microphone as above. Use both capsules as figure of eight pattern. The bottom capsules have to be fixed in 90 degree.

X/Y recording

Use both of the capsules in cardioid pattern. Chose the angle you want by turning the bottom capsule in adequate angle. Turn the microphone to a position so that both capsules point out in same angle Left and Right.

